# CREE 🚓

# Cree® LED Components IES LM-80-2008 Testing Results



Revision: 33 (July 7, 2017)

TABLE OF CONTENTS	
Introduction2	XLamp® ML-E White LEDs (Rev 1)
NVLAP Accreditation for LM-80-2008 Testing2	XLamp® MT-G EasyWhite® LEDs (Rev 1)
LED Modules (Rev 3)3	XLamp® MT-G2 EasyWhite® LEDs (Rev 3)
XLamp® CXA1304 White LEDs (Rev 4)5	XLamp® MX-3 White LEDs (Rev 0)
XLamp® CXA1310 White LEDs (Rev 2)6	XLamp® MX-6 White LEDs (Rev 2)
XLamp® CXA1507 White LEDs (Rev 2)7	XLamp® XB-D White LEDs (Rev 2)
XLamp® CXA1510 White LEDs (Rev 4)8	XLamp® XB-E High Voltage White LEDs (Rev 0) 50
XLamp® CXA1512 White LEDs (Rev 4)9	XLamp® XB-G High Voltage White LEDs (Rev 1)51
XLamp® CXA1520 White LEDs (Rev 2)10	XLamp® XB-H White LEDs (Rev 1)
XLamp® CXA1816 White LEDs (Rev 4)11	XLamp® XH-B White LEDs (Rev 3)53
XLamp® CXA1820 White LEDs (Rev 4)12	XLamp® XH-G White LEDs (Rev 3)54
XLamp® CXA1830 White LEDs (Rev 4)13	XLamp® XHP35 White LEDs (Rev 4)55
XLamp® CXA1850 White LEDs (Rev 2)14	XLamp® XHP50 White LEDs (Rev 4) 56
XLamp® CXA2520 White LEDs (Rev 4)15	XLamp® XHP50.2 White LEDs (Rev 0)57
XLamp® CXA2530 White LEDs (Rev 4)16	XLamp® XHP70 White LEDs (Rev 6) 59
XLamp® CXA2540 White LEDs (Rev 4)17	XLamp® XHP70.2 White LEDs (Rev 0)60
XLamp® CXA2590 White LEDs (Rev 2)18	XLamp® XM-L EasyWhite® LEDs (Rev 1)
XLamp® CXA3050 White LEDs (Rev 4)19	XLamp® XM-L High Voltage White LEDs (Rev 0)
XLamp® CXA3070 White LEDs (Rev 0)20	XLamp® XM-L White LEDs (Rev 2)
XLamp® CXA3590 White LEDs (Rev 0)21	XLamp® XM-L2 White LEDs (Rev 3B)65
XLamp® CXB1304 White LEDs (Rev 7)	XLamp® XP-E High Efficiency White LEDs (Rev 4)
XLamp® CXB1310 White LEDs (Rev 3)	XLamp® XP-E White LEDs (Rev 3)
XLamp® CXB1507 White LEDs (Rev 7)	XLamp® XP-E2 Red, Red-Orange, Amber, Phosphor-Converted
XLamp® CXB1512 White LEDs (Rev 7)	Amber, Green & Blue LEDs (Rev 2)
XLamp® CXB1520 White LEDs (Rev 3)	XLamp® XP-E2 White LEDs (Rev 1)
XLamp® CXB1816 White LEDs (Rev 7)	XLamp® XP-G White LEDs (Rev 7)71
XLamp® CXB1820 White LEDs (Rev 7)	XLamp® XP-G2 White LEDs (Rev 8)
XLamp® CXB1830 White LEDs (Rev 7)	XLamp® XP-G3 White LEDs (Rev 7)
XLamp® CXB2530 White LEDs (Rev 7)	XLamp® XP-L White LEDs (Rev 7)
XLamp® CXB2540 White LEDs (Rev 7)	XLamp® XP-L2 White LEDs (Rev 3)
XLamp® CXB3050 White LEDs (Rev 7)	XLamp® XQ-A Red, Red-Orange, Phosphor-Converted Amber,
XLamp® CXB3070 White LEDs (Rev 7)	Green, Blue & Royal Blue LEDs (Rev 0)
XLamp® CXB3590 White LEDs (Rev 7)	XLamp® XQ-A White LEDs (Rev 0)
XLamp® MC-E White LEDs (Rev 1)	XLamp® XQ-B White LEDs (Rev 1)80
XLamp® MHB-A White LEDs (Rev 10)	XLamp® XQ-D White LEDs (Rev 0)
XLamp® MHB-B White LEDs (Rev 10)	XLamp® XQ-E Red, Red-Orange, Phosphor-Converted Amber,
XLamp® MHD-E White LEDs (Rev 10)	Green, Blue & Royal Blue LEDs (Rev 0)82
XLamp® MHD-G White LEDs (Rev 10)	XLamp® XQ-E White LEDs (Rev 0)
XLamp® MK-R White LEDs (Rev 2)41	XLamp® XR-E White LEDs (Rev 1)
XLamp® ML-B White LEDs (Rev 1)	XLamp® XT-E High Voltage White LEDs (Rev 0)
XLamp® ML-C & ML-E White LEDs (Rev 1)	XLamp® XT-E White LEDs (Rev 10)



#### INTRODUCTION

This document provides the results of Cree's IES LM-80-2008 ("LM-80") testing on its LED components. Cree is providing this data so that the public can verify the reliability of Cree LEDs as part of a complete LED lighting system.

Note that this document provides only the end results of the LM-80 tests. This is not a complete LM-80 report. Do not use this document to submit luminaires or lamps to an agency. Cree customers who need the full LM-80 reports should contact their Cree sales representative.

Cree's customers who wish to share LM-80 results with their customers have permission to link to this document from their website. This document is subject to change without notice, so please do not link to a local copy.

#### **NVLAP ACCREDITATION FOR LM-80-2008 TESTING**

Cree's SSL testing laboratory in Durham, NC, USA is accredited by the National Voluntary Laboratory Accreditation Program (NVLAP) to perform IES LM-80-2008 testing. All LM-80-2008 results produced by Cree are generated in Cree's accredited laboratory. Full details on Cree's NVLAP accreditation are available here:

https://www-s.nist.gov/niws/index.cfm?event=directory.search#no-back

This report must not be used to claim product certification, approval, or endorsement by the NVLAP, the National Institute of Standards and Technology (NIST) or any other agency of the federal government.



#### **LED MODULES (REV 3)**

Revision: 3 (March 12, 2014)

#### **Description Of LED Light Sources**

Module Family	Nominal Light Output	Applicable Order Codes	Maximum LED Current*	Maximum Tc**	Maximum LED Tsp
LMR2	650 lm	LMR020-0650-xxxx-xxxxxTW	450 mA	74 °C	85 °C
LMR4	700 lm	LMR040-0700-xxxx-xxxxxTW	450 mA	77 °C	85 °C
LIVIK4	1000 lm	LMR040-1000-xxxx-xxxxxTW	450 mA	75 °C	85 °C
	850 lm	LMH020-0850-xxxx-xxxxxTW	440 mA	77 °C	85 °C
LMH2	1250 lm	LMH020-1250-xxxx-xxxxxTW	440 mA	75 °C	85 °C
LMH2	2000 lm	LMH020-2000-xxxx-xxxxxTW	450 mA	70 °C	85 °C
	3000 lm	LMH020-3000-xxxx-xxxxxTW	450 mA	68 °C	85 °C

No failures occurred during testing.

#### **Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [ا <sub>ج</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	White: 700 mA Single-Color: 1000 mA	2700 K	25	7,056 hrs	L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
1+	85 °C	85 °C	White: 700 mA Single-Color: 1000 mA	2700 K	21	16,128 hrs	L90(16k) = 27,200 hrs L80(16k) = 57,400 hrs L70(16k) = 91,600 hrs

#### Notes:

- \* Maximum LED Current: These values are the maximum current that the white and single-color LEDs will receive during operation in the specified module.
- \*\* Maximum Tc: There is no practical way to directly measure LED Tsp inside Cree's module without adversely affecting the module's optical, thermal or mechanical properties. Therefore, Cree has characterized samples of our LED modules for the temperature difference between LED Tsp and the Cree-specified Tc measurement point on the outside of the module. Cree recommends using the external Tc measurement point and the maximum Tc values listed in the table above.



# **LED MODULES (REV 3) - CONTINUED**

#### **Description Of Additional LED Light Sources**

The following data sets apply to the additional Cree LED modules in the table below:

Module Family	Data Set	Nominal Light Output	Applicable Order Codes	Maximum LED Current*	Maximum Tc**	Maximum LED Tsp
LMH2	2	4000 lm	LMH020-4000-xxxx-xxxxxTW	470 mA	75 °C	105 °C
	LMH2 3	4000 lm	LMH020-4000-xxxx-xxxxxTW	470 mA	55 °C	85 °C
LMH2		6000 lm	LMH020-6000-xxxx-xxxxxTW	850 mA	78 °C	85 °C
		8000 lm	LMH020-8000-xxxx-xxxxxTW	1000 mA	75 °C	85 °C

No failures occurred during testing.

#### **Additional Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
2	105 °C	105 °C	White: 700 mA Single-Color: 1000 mA	3500 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	85 °C	85 °C	White: 1000 mA Single-Color: 1000 mA	3500 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs

#### Notes:

- \* Maximum LED Current: These values are the maximum current that the white and single-color LEDs will receive during operation in the specified module.
- \*\* Maximum Tc: There is no practical way to directly measure LED Tsp inside Cree's module without adversely affecting the module's optical, thermal or mechanical properties. Therefore, Cree has characterized samples of our LED modules for the temperature difference between LED Tsp and the Cree-specified Tc measurement point on the outside of the module. Cree recommends using the external Tc measurement point and the maximum Tc values listed in the table above.



#### XLAMP® CXA1304 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp® CXA1304 White LEDs (Series: CXA1304)

This LM-80 report is applicable to the following order codes:

CXA1304 9 V CXA1304-xxxx-xxxCxxxxxxx CXA1304 18 V CXA1304-xxxx-xxxFxxxxxxx CXA1304 36 V CXA1304-xxxx-xxxNxxxxxxx

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA1304	9 V	CXA1304-xxxx-xxxCxxxxxxx	460 mA	524 mA	692 mA	768 mA	
CXA1304	18 V	CXA1304-xxxx-xxxFxxxxxxx	230 mA	262 mA	346 mA	384 mA	
CXA1304	36 V	CXA1304-xxxx-xxxNxxxxxxx	115 mA	131 mA	173 mA	192 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



#### XLAMP® CXA1310 WHITE LEDS (REV 2)

Revision: 2 (February 24, 2017)

# **Description Of LED Light Sources**

XLamp CXA1310 White LEDs (Series: CXA1310)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1520-1	105 °C	105 °C	500 mA	3000 K	24	8,568 hrs	L90(9k) = 37,300 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
1520-2	85 °C	85 °C	700 mA	3000 K	21	9,072 hrs	L90(9k) = 52,200 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs

# **Scaling For Applicable Products**

			Applicable Currents			
Product Name	Voltage Class	Product Order Code	Data Set 1520-1 (105°C)	Data Set 1520-2 (85°C)		
CXA1310	18 V	CXA1310-xxxx-xxxFxxxxxxx	600 mA	840 mA		
CXA1310	36 V	CXA1310-xxxx-xxxNxxxxxxx	300 mA	420 mA		
CXA1520	36 V	CXA1520-xxxx-xxxNxxxxxxx	500 mA	700 mA		



# XLAMP® CXA1507 WHITE LEDS (REV 2)

Revision: 2 (March 19, 2014)

# **Description Of LED Light Sources**

XLamp CXA1507 White LEDs (Series: CXA1507)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	55 °C	55 °C	200 mA (36 V) 400 mA (18 V)	3000 K	25	6,048 hrs	L95(6k) = 24,700 hrs L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	85 °C	85 °C	200 mA (36 V) 400 mA (18 V)	3000 K	25	6,048 hrs	L95(6k) = 26,600 hrs L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	105°C	105 °C	200 mA (36 V) 400 mA (18 V)	3000 K	25	6,048 hrs	L95(6k) = 19,700 hrs L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3+	105 °C	105 °C	200 mA (36 V) 400 mA (18 V)	3000 K	20	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
4	55 °C	55 °C	375 mA (36 V) 750 mA (18 V)	3000 K	25	6,048 hrs	L90(6k) = 30,200 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4+	55 °C	55 °C	375 mA (36 V) 750 mA (18 V)	3000 K	24	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	85 °C	85 °C	375 mA (36 V) 750 mA (18 V)	3000 K	25	7,056 hrs	L90(7k) = 39,600 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
5+	85 °C	85 °C	375 mA (36 V) 750 mA (18 V)	3000 K	20	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs



# XLAMP® CXA1510 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA1510 White LEDs (Series: CXA1510)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA1510	18 V	CXA1510-xxxx-xxxFxxxxxxx	468 mA	530 mA	702 mA	780 mA	
CXA1510	36 V	CXA1510-xxxx-xxxNxxxxxxx	234 mA	265 mA	351 mA	390 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA1512 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA1512 White LEDs (Series: CXA1512)

This LM-80 report is applicable to the following order codes:

CXA1512 18 V CXA1512-xxxx-xxxFxxxxxxx CXA1512 36 V CXA1512-xxxx-xxxNxxxxxxx

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA1512	18 V	CXA1512-xxxx-xxxFxxxxxxx	692 mA	784 mA	1038 mA	1154 mA	
CXA1512	36 V	CXA1512-xxxx-xxxNxxxxxxx	346 mA	392 mA	519 mA	577 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA1520 WHITE LEDS (REV 2)

Revision: 2 (February 24, 2017)

# **Description Of LED Light Sources**

XLamp CXA1520 White LEDs (Series: CXA1520)

This LM-80 report is applicable to the following order codes:

CXA1520-xxxx-xxxxxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1520-1	105 °C	105 °C	500 mA	3000 K	24	8,568 hrs	L90(9k) = 37,300 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
1520-2	85 °C	85 °C	700 mA	3000 K	21	9,072 hrs	L90(9k) = 52,200 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs



# XLAMP® CXA1816 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA1816 White LEDs (Series: CXA1816)

This LM-80 report is applicable to the following order codes:

CXA1816-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA1816	36 V	CXA1816-xxxx-xxxNxxxxxxx	462 mA	523 mA	692 mA	769 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA1820 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA1820 White LEDs (Series: CXA1820)

This LM-80 report is applicable to the following order codes:

CXA1820-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA1820	36 V	CXA1820-xxxx-xxxNxxxxxxx	577 mA	654 mA	865 mA	962 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA1830 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA1830 White LEDs (Series: CXA1830)

This LM-80 report is applicable to the following order codes:

CXA1830-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

	Voltage Class		Applicable Currents				
Product Name		Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA1830	36 V	CXA1830-xxxx-xxxNxxxxxxx	662 mA	743 mA	977 mA	1087 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA1850 WHITE LEDS (REV 2)

Revision: 2 (February 24, 2017)

# **Description Of LED Light Sources**

XLamp CXA1850 White LEDs (Series: CXA1850)

This LM-80 report is applicable to the following order codes:

CXA1850-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
2590-1	105 °C	105 °C	700 mA	3000 K	25	7,056 hrs	L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
2590-2	105 °C	105 °C	1050 mA	3000 K	20	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2590-3	85 °C	85 °C	1400 mA	3000 K	25	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
2590-3+	85 °C	85 °C	1400 mA	3000 K	14	11,592 hrs	L90(12k) > 63,800 hrs L80(12k) > 63,800 hrs L70(12k) > 63,800 hrs

#### **Scaling For Applicable Products**

			Applicable Currents			
Product Name	Voltage Class	Product Order Code	Data Set 2590-1 (105°C)	Data Set 2590-2 (105°C)	Data Set 2590-3+ (85°C)	
CXA1850	36 V	CXA1850-xxxx-xxxNxxxxxxx	750 mA	1500 mA	1540 mA	
CXA2590	72 V	CXA2590-xxxx-xxxRxxxxxxx	700 mA	1050 mA	1400 mA	



#### XLAMP® CXA2520 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA2520 White LEDs (Series: CXA2520)

This LM-80 report is applicable to the following order codes:

CXA2520-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

	Voltage Class		Applicable Currents				
Product Name		Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA2520	36 V	CXA2520-xxxx-xxxNxxxxxxx	624 mA	707 mA	936 mA	1040 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA2530 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA2530 White LEDs (Series: CXA2530)

This LM-80 report is applicable to the following order codes:

CXA2530-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA2530	36 V	CXA2530-xxxx-xxxNxxxxxxx	808 mA	915 mA	1212 mA	1346 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA2540 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA2540 White LEDs (Series: CXA2540)

This LM-80 report is applicable to the following order codes:

CXA2540-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

	Voltage Class		Applicable Currents				
Product Name		Product Order Code	Data Set 3050-4(+) (105°C)	Data Set 3050-5 (85°C)	Data Set 3050-6 (85°C)	Data Set 3050-3 (55°C)	
CXA2540	36 V	CXA2540-xxxx-xxxNxxxxxxx	1139 mA	1281 mA	1693 mA	1903 mA	
CXA3050	36 V	CXA3050-xxxx-xxxNxxxxxxx	1500 mA	1700 mA	2250 mA	2500 mA	



# XLAMP® CXA2590 WHITE LEDS (REV 2)

Revision: 2 (February 24, 2017)

# **Description Of LED Light Sources**

XLamp CXA2590 White LEDs (Series: CXA2590)

This LM-80 report is applicable to the following order codes:

CXA2590-xxxx-xxxxxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
2590-1	105 °C	105 °C	700 mA	3000 K	25	7,056 hrs	L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
2590-2	105 °C	105 °C	1050 mA	3000 K	20	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2590-3	85 °C	85 °C	1400 mA	3000 K	25	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
2590-3+	85 °C	85 °C	1400 mA	3000 K	14	11,592 hrs	L90(12k) > 63,800 hrs L80(12k) > 63,800 hrs L70(12k) > 63,800 hrs



# XLAMP® CXA3050 WHITE LEDS (REV 4)

Revision: 4 (September 11, 2015)

# **Description Of LED Light Sources**

XLamp CXA3050 White LEDs (Series: CXA3050)

This LM-80 report is applicable to the following order codes:

CXA3050-xxxx-xxxxxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3050-4	105 °C	105 °C	1500 mA	3000 K	25	8,064 hrs	L90(8k) = 27,000 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
3050-4+	105 °C	105 °C	1500 mA	3000 K	22	10,080 hrs	L90(10k) = 35,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3050-5	85 °C	85 °C	1700 mA	3000 K	25	10,584 hrs	L90(10k) = 50,700 hrs L80(10k) > 63,500 hrs L70(10k) > 63,500 hrs
3050-6	85 °C	85 °C	2250 mA	3000 K	25	7,056 hrs	L90(7k) = 37,400 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
3050-3	55 °C	55 °C	2500 mA	3000 K	25	10,080 hrs	L90(10k) = 55,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs



# XLAMP® CXA3070 WHITE LEDS (REV 0)

Revision: 0 (September 5, 2014)

# **Description Of LED Light Sources**

XLamp CXA3070 White LEDs (Series: CXA3070)

This LM-80 report is applicable to the following order codes:

CXA3070-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3590-1	105 °C	105 °C	1050 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3590-2	85 °C	85 °C	1400 mA	3000 K	25	6,046 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs

#### **Scaling For Applicable Products**

			Applicable Currents		
Product Name	Voltage Class	Product Order Code	Data Set 3590-1 (105 °C)	Data Set 3590-2 (85° C)	
CXA3070	36 V	CXA3070-xxxx-xxxNxxxxxxx	1335 mA	1794 mA	
CXA3590	72 V	CXA3590-xxxx-xxxRxxxxxxx	1050 mA	1400 mA	



# XLAMP® CXA3590 WHITE LEDS (REV 0)

Revision: 0 (September 5, 2014)

# **Description Of LED Light Sources**

XLamp CXA3590 White LEDs (Series: CXA3590)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

#### **Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3590-1	105 °C	105 °C	1050 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3590-2	85 °C	85 °C	1400 mA	3000 K	25	6,046 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs

# **Scaling For Applicable Products**

			Applicable Currents		
Product Name	Voltage Class	Product Order Code	Data Set 3590-1 (105 °C)	Data Set 3590-2 (85° C)	
CXA3590	36 V	CXA3590-xxxx-xxxNxxxxxxx	2100 mA	2800 mA	
CXA3590	72 V	CXA3590-xxxx-xxxRxxxxxxx	1050 mA	1400 mA	



#### XLAMP® CXB1304 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB1304 White LEDs (Series: CXB1304)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

# **Results Summary For Tested LED Arrays**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B2530-1	105 °C	105 °C	1200 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B2530-2	85 °C	85 °C	1600 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs

# **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set B2530-1 (105°C)	Data Set B2530-2 (85°C)	Data Set B3050-1 (105°C)	Data Set B3050-2 (85°C)	
CXB1304	9 V	CXB1304-xxxx-xxxCxxxxxxx	684 mA	916 mA	460 mA	768 mA	
CXB1304	18 V	CXB1304-xxxx-xxxFxxxxxxx	342 mA	458 mA	230 mA	384 mA	
CXB1304	36 V	CXB1304-xxxx-xxxNxxxxxxx	171 mA	229 mA	115 mA	192 mA	
CXB2530	36 V	CXB2530-xxxx-xxxNxxxxxxx	1200 mA	1600 mA			
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx			1500 mA	2500 mA	



# XLAMP® CXB1310 WHITE LEDS (REV 3)

Revision: 3 (June 2, 2017)

# **Description Of LED Light Sources**

XLamp CXB1310 White LEDs (Series: CXB1310)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B1310-1	85 °C	85 °C	900 mA (18 V) 450 mA (36 V)	3000K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B1310-2	105 °C	105 °C	900 mA (18 V) 450 mA (36 V)	3000K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B1310-3	85 °C	85 °C	1200 mA (18 V) 600 mA (36 V)	3000K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B1310-4	85 °C	85 °C	1400 mA (18 V) 700 mA (36 V)	3000K	10	8,568 hrs	L90(9k) > 47,100 hrs L80(9k) > 47,100 hrs L70(9k) > 47,100 hrs



#### XLAMP® CXB1507 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB1507 White LEDs (Series: CXB1507)

This LM-80 report is applicable to the following order codes:

CXB1507 18 V CXB1507-xxxx-xxxFxxxxxxx CXB1507 36 V CXB1507-xxxx-xxxNxxxxxxx

No failures occurred during testing.

#### **Results Summary For Tested LED Arrays**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B2530-1	105 °C	105 °C	1200 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs

#### **Scaling For Applicable Products**

			Applicable Currents			
Product Name	Voltage Class	Product Order Code	Data Set B2530-1 (105°C)	Data Set B3050-1 (105°C)	Data Set B3050-2 (85°C)	
CXB1507	18 V	CXB1507-xxxx-xxxFxxxxxxx	686 mA	462 mA	750 mA	
CXB1507	36 V	CXB1507-xxxx-xxxNxxxxxxx	343 mA	231 mA	375 mA	
CXB2530	36 V	CXB2530-xxxx-xxxNxxxxxxx	1200 mA			
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx		1500 mA	2500 mA	



#### XLAMP® CXB1512 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB1512 White LEDs (Series: CXB1512)

This LM-80 report is applicable to the following order codes:

CXB1512 18 V CXB1512-xxxx-xxxFxxxxxxx CXB1512 36 V CXB1512-xxxx-xxxNxxxxxxx

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs

# **Scaling For Applicable Products**

			Applicable Currents			
Product Name	Voltage Class	Product Order Code	Data Set B3050-1 (105°C)	Data Set B3050-2 (85°C)		
CXB1512	18 V	CXB1512-xxxx-xxxFxxxxxxx	900 mA	1200 mA		
CXB1512	36 V	CXB1512-xxxx-xxxNxxxxxxx	450 mA	600 mA		
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx	1500 mA	2500 mA		



# XLAMP® CXB1520 WHITE LEDS (REV 3)

Revision: 3 (June 2, 2017)

# **Description Of LED Light Sources**

XLamp CXB1520 White LEDs (Series: CXB1520)

This LM-80 report is applicable to the following order codes:

CXB1520-xxxx-xxxxxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B1520-1	85 °C	85 °C	900 mA	3000 K	20	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
B1520-2	105 °C	105 °C	900 mA	3000 K	20	9,072 hrs	L90(9k) = 42,600 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
B1520-3	85 °C	85 °C	1200 mA	3000 K	15	8,064 hrs	L90(8k) > 44,400 hrs L80(8k) > 44,400 hrs L70(8k) > 44,400 hrs
B1520-4	85 °C	85 °C	1400 mA	2700 K & 3000 K	15	8,064 hrs	L90(8k) > 44,400 hrs L80(8k) > 44,400 hrs L70(8k) > 44,400 hrs



# XLAMP® CXB1816 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB1816 White LEDs (Series: CXB1816)

This LM-80 report is applicable to the following order codes:

CXB1816-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Arrays**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B2530-1	105 °C	105 °C	1200 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B2530-2	85 °C	85 °C	1600 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs

#### **Scaling For Applicable Products**

		Product Order Code	Applicable Currents				
Product Name	Voltage Class		Data Set B2530-1 (105°C)	Data Set B2530-2 (85°C)	Data Set B3050-1 (105°C)	Data Set B3050-2 (85°C)	
CXB1816	36 V	CXB1816-xxxx-xxxNxxxxxxx	673 mA	900 mA	462 mA	769 mA	
CXB2530	36V	CXB2530-xxxx-xxxNxxxxxxx	1200 mA	1600 mA			
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx			1500 mA	2500 mA	



#### XLAMP® CXB1820 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB1820 White LEDs (Series: CXB1820)

This LM-80 report is applicable to the following order codes:

CXB1820-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Arrays**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B2530-1	105 °C	105 °C	1200 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3070-1	105 °C	105 °C	2250 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs
B3070-2	85 °C	85 °C	2800 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs

#### **Scaling For Applicable Products**

			Applicable Currents					
Product Name	Voltage Class	Product Order Code	Data Set 2530-1 (105°C)	Data Set B3050-1 (105°C)	Data Set B3050-2 (85 °C)	Data Set B3070-1 (105°C)	Data Set B3070-2 (85 °C)	
CXB1820	36 V	CXB1820-xxxx-xxxNxxxxxxx	681 mA	630 mA	1044 mA	727 mA	1018 mA	
CXB2530	36 V	CXB2530-xxxx-xxxNxxxxxxx	1200 mA					
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx		1500 mA	2500 mA			
CXB3070	36 V	CXB3070-xxxx-xxxNxxxxxxx				2250 mA	2800 mA	



#### XLAMP® CXB1830 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB1830 White LEDs (Series: CXB1830)

This LM-80 report is applicable to the following order codes:

CXB1830-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Arrays**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B2530-1	105 °C	105 °C	1200 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3070-1	105 °C	105 °C	2250 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs
B3070-2	85 °C	85 °C	2800 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs

#### **Scaling For Applicable Products**

Product Name	Voltage Class	Product Order Code	Data Set 2530-1 (105°C)	Data Set B3050-1 (105°C)	Data Set B3050-2 (85 °C)	Data Set B3070-1 (105°C)	Data Set B3070-2 (85 °C)
CXB1830	36 V	CXB1830-xxxx-xxxNxxxxxxx	707 mA	653 mA	1094 mA	984 mA	1227 mA
CXB2530	36 V	CXB2530-xxxx-xxxNxxxxxxx	1200 mA				
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx		1500 mA	2500 mA		
CXB3070	36 V	CXB3070-xxxx-xxxNxxxxxxx				2250 mA	2800 mA



#### XLAMP® CXB2530 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB2530 White LEDs (Series: CXB2530)

This LM-80 report is applicable to the following order codes:

CXB2530-xxxx-xxxxxxxxxxx

No failures occurred during testing.

#### **Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B2530-1	105 °C	105 °C	1200 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B2530-2	85 °C	85 °C	1600 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs

#### **Scaling For Applicable Products**

			Applicable Currents		
Product Name	Voltage Class	Product Order Code	Data Set B3050-1 (105°C)	Data Set B3050-2 (85°C)	
CXB2530	36 V	CXB2530-xxxx-xxxNxxxxxxx	808 mA	1346 mA	
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx	1500 mA	2500 mA	



#### XLAMP® CXB2540 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB2540 White LEDs (Series: CXB2540)

This LM-80 report is applicable to the following order codes:

CXB2540-xxxx-xxxxxxxxxxx

No failures occurred during testing.

# **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3070-1	105 °C	105 °C	2250 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs
B3070-2	85 °C	85 °C	2800 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs

#### **Scaling For Applicable Products**

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set B3050-1 (105°C)	Data Set B3050-2 (85°C)	Data Set B3070-1 (105°C)	Data Set B3070-2 (85°C)	
CXB2540	36 V	CXB2540-xxxx-xxxNxxxxxxx	1146 mA	1923 mA	1262 mA	1571 mA	
CXB3050	36V	CXB3050-xxxx-xxxNxxxxxxx	1500 mA	2500 mA			
CXB3070	36 V	CXB3070-xxxx-xxxNxxxxxxx			2250 mA	2800 mA	



#### XLAMP® CXB3050 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

#### **Description Of LED Light Sources**

XLamp CXB3050 White LEDs (Series: CXB3050)

This LM-80 report is applicable to the following order codes:

CXB3050-xxxx-xxxxxxxxxxx

No failures occurred during testing.

#### **Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3050-1	105 °C	105 °C	1500 mA	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3050-2	85 °C	85 °C	2500 mA	3000 K	10	10,080 hrs	L90(10k) > 55,400 hrs L80(10k) > 55,400 hrs L70(10k) > 55,400 hrs

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3070-1	105 °C	105 °C	2250 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B3070-2	85 °C	85 °C	2800 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs

#### **Scaling For Applicable Products**

			Applicable Currents		
Product Name	Voltage Class	Product Order Code	Data Set B3070-1 (105°C)	Data Set B3070-2 (85°C)	
CXB3050	36 V	CXB3050-xxxx-xxxNxxxxxxx	1641 mA	2042 mA	
CXB3070	36 V	CXB3070-xxxx-xxxNxxxxxxx	2250 mA	2800 mA	



#### XLAMP® CXB3070 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB3070 White LEDs (Series: CXB3070)

This LM-80 report is applicable to the following order codes:

CXB3070-xxxx-xxxxxxxxxxx

No failures occurred during testing.

#### **Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3070-1	105 °C	105 °C	2250 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
B3070-2	85 °C	85 °C	2800 mA	3000 K	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3590-1	105 °C	105 °C	2100 mA (36 V) 1050 mA (72 V)	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3590-2	85 °C	85 °C	2800 mA (36 V) 1400 mA (72 V)	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs

#### **Scaling For Applicable Products**

			Applicable Currents		
Product Name	Voltage Class	Product Order Code	Data Set B3590-1 (105 °C)	Data Set B3590-2 (85°C)	
CXB3070	36 V	CXB3070-xxxx-xxxNxxxxxxx	1321 mA	1764 mA	
CXB3590	72 V	CXB3590-xxxx-xxxRxxxxxxx	1050 mA	1400 mA	



# XLAMP® CXB3590 WHITE LEDS (REV 7)

Revision: 7 (May 19, 2017)

# **Description Of LED Light Sources**

XLamp CXB3590 White LEDs (Series: CXB3590)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
B3590-1	105 °C	105 °C	2100 mA (36 V) 1050 mA (72 V)	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
B3590-2	85 °C	85 °C	2800 mA (36 V) 1400 mA (72 V)	3000 K	10	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs



# XLAMP® MC-E WHITE LEDS (REV 1)

Revision: 1 (December 8, 2010)

# **Description Of LED Light Sources**

XLamp MC-E White LEDs (Series: MCE4WT)
XLamp MC-E EasyWhite® LEDs (Series: MCEEZW)

This LM-80 report is applicable to the following order codes:

MC-E White: MCE4WT-A2-xxxx-xxxxxx

MC-E EasyWhite: MCEEZW-A1-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	45 °C	45 °C	350 mA	3000 K	26	6,048 hrs	L90(6k) > 25,700 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	55 °C	55 °C	350 mA	3000 K	26	6,048 hrs	L90(6k) = 28,800 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	85 °C	85 °C	350 mA	3000 K	26	6,048 hrs	L90(6k) = 23,100 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	45 °C	45 °C	700 mA	3000 K	26	6,048 hrs	L90(6k) = 23,600 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4	55 °C	55 °C	700 mA	3000 K	26	6,048 hrs	L90(6k) = 11,700 hrs L80(6k) = 21,900 hrs L70(6k) = 33.400 hrs
6	85 °C	85 °C	700 mA	3000 K	26	6,048 hrs	L90(6k) = 7,660 hrs L80(6k) = 13,900 hrs L70(6k) = 20,900 hrs



# XLAMP® MHB-A WHITE LEDS (REV 10)

Revision: 10 (July 6, 2017)

# **Description Of LED Light Sources**

XLamp MHB-A White LEDs (Series: MHBAWT)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
MHBA-2	105 °C	105 °C	320 mA (9 V) 160 mA (18 V) 80 mA (36 V)	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
MHBA-2+	105 °C	105 °C	320 mA (9 V) 160 mA (18 V) 80 mA (36 V)	3000 K	20	14,112 hrs	L90(14k) > 84,700 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
МНВА-3	85 °C	85 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	24	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
МНВА-3+	85 °C	85 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	21	14,112 hrs	L90(14k) > 84,700 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
MHBA-1	105 °C	105 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	23	8,568 hrs	L90(9k) = 30,200 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
MHBA-4	85 °C	85 °C	700 mA (9 V) 350 mA (18 V) 175 mA (36 V)	3000 K	20	8,568 hrs	L90(9k) = 21,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs



#### XLAMP® MHB-B WHITE LEDS (REV 10)

Revision: 10 (July 6, 2017)

# **Description Of LED Light Sources**

XLamp MHB-B White LEDs (Series: MHBBWT)

This LM-80 report is applicable to the following order codes:

MHB-B 9 V: MHBBWT-xxxx-xxxCxxxxxxx
MHB-B 18 V: MHBBWT-xxxx-xxxFxxxxxxx
MHB-B 36 V: MHBBWT-xxxx-xxxNxxxxxxx

No failures occurred during testing.

#### **Test Summary**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
MHBB-2	105 °C	105 °C	320 mA (9 V) 160 mA (18 V) 80 mA (36 V)	3000 K	20	6,552 hrs	L90(7k) > 39,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs
МНВВ-3	85 °C	85 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	20	6,552 hrs	L90(7k) > 39,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs
MHBB-1	105 °C	105 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	20	6,552 hrs	L90(7k) > 39,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs
MHBB-5	105 °C	105 °C	600 mA (9 V) 390 mA (18 V) 150 mA (36 V)	3000 K	20	6,552 hrs	L90(7k) > 39,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs
MHBB-4	85 °C	85 °C	700 mA (9 V) 350 mA (18 V) 175 mA (36 V)	3000 K	20	6,552 hrs	L90(7k) > 39,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
MHBA-2	105 °C	105 °C	320 mA (9 V) 160 mA (18 V) 80 mA (36 V)	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
МНВА-3	85 °C	85 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	24	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
MHBA-1	105 °C	105 °C	500 mA (9 V) 250 mA (18 V) 125 mA (36 V)	3000 K	23	8,568 hrs	L90(9k) = 30,200 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
MHBA-4	85 °C	85 °C	700 mA (9 V) 350 mA (18 V) 175 mA (36 V)	3000 K	20	8,568 hrs	L90(9k) = 21,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs



#### XLAMP® MHB-B WHITE LEDS (REV 10) - CONTINUED

#### **Scaling For Applicable Products**

The data sets cited below meet all the criteria for one LM-80 data set to apply to a range of LED arrays, as defined in the ENERGY STAR September 9, 2011 guidelines, Section 3.7.d. The table below defines the current values that apply to each product when scaled from the tested LM-80 product. The tested product is listed in bold text below.

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set MHBA-2 (105°C)	Data Set MHBA-3 (85°C)	Data Set MHBA-1 (105°C)	Data Set MHBA-4 (85°C)	
MHB-B	9 V	MHBBWT-xxxx-xxxCxxxxxxx	332 mA	524 mA	524 mA	700 mA	
MHB-B	18 V	MHBBWT-xxxx-xxxFxxxxxxx	166 mA	262 mA	262 mA	350 mA	
MHB-B	36 V	MHBBWT-xxxx-xxxNxxxxxxx	83 mA	131 mA	131 mA	175 mA	
MHB-A	36 V	MHBAWT-xxxx-xxxNxxxxxxx	80 mA	125 mA	125 mA	175 mA	



#### XLAMP® MHD-E WHITE LEDS (REV 10)

Revision: 10 (July 6, 2017)

## **Description Of LED Light Sources**

XLamp MHD-E White LEDs (Series: MHDEWT)

This LM-80 report is applicable to the following order codes:

MHD-E 9 V: MHDEWT-xxxx-xxxCxxxxxxx
MHD-E 18 V: MHDEWT-xxxx-xxxFxxxxxxx
MHD-E 36 V: MHDEWT-xxxx-xxxNxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
MHDE-1	105 °C	105 °C	600 mA (9 V) 300 mA (18 V) 150 mA (36 V)	3000 K	20	11,592 hrs	L90(12k) > 69,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs
MHDE-2	85 °C	85 °C	1000 mA (9 V) 500 mA (18 V) 250 mA (36 V)	3000 K	20	11,592 hrs	L90(12k) > 69,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs



#### XLAMP® MHD-G WHITE LEDS (REV 10)

Revision: 10 (July 6, 2017)

## **Description Of LED Light Sources**

XLamp MHD-G White LEDs (Series: MHDGWT)

This LM-80 report is applicable to the following order codes:

MHD-G 18 V: MHDGWT-xxxx-xxxFxxxxxxx MHD-G 36 V: MHDGWT-xxxx-xxxNxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
MHDG-1	105 °C	105 °C	400 mA (18 V) 200 mA (36 V)	3000 K	20	8,064 hrs	L90(8k) > 48,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
MHDG-1+	105 °C	105 °C	400 mA (18 V) 200 mA (36 V)	3000K	18	12,096 hrs	L90(12k) = 44,900 hrs L80(12k) > 66,500 hrs L70(12k) > 66,500 hrs
MHDG-4	85 °C	85 °C	500 mA (18 V) 250 mA (36 V)	3000K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
MHDG-4+	85 °C	85 °C	500 mA (18 V) 250 mA (36 V)	3000K	20	8,568 hrs	L90(9k) > 51,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
MHDG-5	105 °C	105 °C	500 mA (18 V) 250 mA (36 V)	3000K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
MHDG-2	105 °C	105 °C	700 mA (18 V) 350 mA (36 V)	3000 K	20	6,048 hrs	L90(6k) = 11,500 hrs L80(6k) = 28,400 hrs L70(6k) > 36,300 hrs
MHDG-3	85 °C	85 °C	800 mA (18 V) 400 mA (36 V)	3000 K	20	8,568 hrs	L90(9k) = 24,600 hrs L80(9k) = 51,400 hrs L70(9k) > 51,400 hrs



#### XLAMP® MK-R WHITE LEDS (REV 2)

Revision: 2 (May 12, 2015)

# **Description Of LED Light Sources**

XLamp MK-R White LEDs (Series: MKRAWT)

This LM-80 report is applicable to the following order codes:

MK-R 6 V: MKRAWT-xx-xxxx-xBxxxxxxxxx

MK-R 12 V: MKRAWT-xx-xxxx-xDxxxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3	125 °C	125 °C	700 mA (6 V) 350 mA (12 V)	3000 K	25	11,088 hrs	L90(11k) > 66,500 hrs L80(11k) > 66,500 hrs L70(11k) > 66,500 hrs
8	105 °C	105 °C	1000 mA (6 V) 500 mA (12 V)	3000 K	25	13,104 hrs	L90(13k) = 34,800 hrs L80(13k) = 75,600 hrs L70(13k) > 78,600 hrs
9	85 °C	85 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	25	13,104 hrs	L90(13k) = 36,400 hrs L80(13k) > 78,600 hrs L70(13k) > 78,600 hrs
4	105 °C	105 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	25	10,080 hrs	L90(10k) = 26,900 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	85 °C	85 °C	2000 mA (6 V) 1000 mA (12 V)	3000 K	25	11,088 hrs	L90(11k) = 30,500 hrs L80(11k) = 62,200 hrs L70(11k) > 66,500 hrs
6	55 °C	55 °C	2500 mA (6 V) 1250 mA (12 V)	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
6+	55 °C	55 °C	2500 mA (6 V) 1250 mA (12 V)	3000 K	21	7,056 hrs	L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
7	85 °C	85 °C	2500 mA (6 V) 1250 mA (12 V)	3000 K	25	6,048 hrs	L90(6k) = 33,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
7+	85 °C	85 °C	2500 mA (6 V) 1250 mA (12 V)	3000 K	22	8,064 hrs	L90(8k) = 19,800 hrs L80(8k) = 42,600 hrs L70(8k) > 48,400 hrs



#### XLAMP® ML-B WHITE LEDS (REV 1)

Revision: 1 (May 1, 2012)

## **Description Of LED Light Sources**

XLamp ML-B White LEDs (Series: MLBAWT)

This LM-80 report is applicable to the following order codes:

MLBAWT-xx-xxxx-xxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	45 °C	45 °C	80 mA	2700 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	55 °C	55 °C	80 mA	2700 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	85 °C	85 °C	80 mA	2700 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4	85 °C	85 °C	175 mA	2700 K	25	8,064 hrs	L90(8k) = 12,300 hrs L80(8k) = 23,600 hrs L70(8k) = 36,300 hrs



#### XLAMP® ML-C & ML-E WHITE LEDS (REV 1)

Revision: 1 (March 19, 2012)

#### **Description Of LED Light Sources**

XLamp ML-C White LEDs (Parallel (MLCAWT) & Series (MLCSWT) Configurations) XLamp ML-E White LEDs (Parallel (MLEAWT) & Series (MLESWT) Configurations)

This LM-80 report is applicable to the following order codes:

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	45 °C	45 °C	116 mA (MLCAWT) 58 mA (MLCSWT) 175 mA (MLEAWT) 58 mA (MLESWT)	2700 K	26	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	55 °C	55 °C	116 mA (MLCAWT) 58 mA (MLCSWT) 175 mA (MLEAWT) 58 mA (MLESWT)	2700 K	26	6,048 hrs	L90(6k) = 25,600 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	85 °C	85 °C	116 mA (MLCAWT) 58 mA (MLCSWT) 175 mA (MLEAWT) 58 mA (MLESWT)	2700 K	26	6,048 hrs	L90(6k) = 13,600 hrs L80(6k) = 27,200 hrs L70(6k) > 36,300 hrs



#### XLAMP® ML-E WHITE LEDS (REV 1)

Revision: 1 (June 14, 2013)

## **Description Of LED Light Sources**

XLamp ML-E White LEDs (Series: MLEAWT)

This LM-80 report is applicable to the following order codes:

MLEAWT-xx-xxxx-xxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
P2	55 °C	55 °C	175 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
P3	85 °C	85 °C	175 mA	3000 K	25	6,552 hrs	L90(7k) = 24,700 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs
P3+	85 °C	85 °C	175 mA	3000 K	20	10,584 hrs	L90(11k) = 17,100 hrs L80(11k) = 29,900 hrs L70(11k) = 44,300 hrs
P1	105 °C	105 °C	175 mA	3000 K	25	6,048 hrs	L90(6k) = 10,200 hrs L80(6k) = 18,700 hrs L70(6k) = 28,300 hrs
P4	55 °C	55 °C	350 mA	3000 K	25	6,048 hrs	L90(6k) = 23,000 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
P5	85 °C	85 °C	350 mA	3000 K	25	6,048 hrs	L90(6k) = 9,450 hrs L80(6k) = 18,600 hrs L70(6k) = 28,900 hrs



#### XLAMP® MT-G EASYWHITE® LEDS (REV 1)

Revision: 1 (February 16, 2012)

## **Description Of LED Light Sources**

XLamp MT-G EasyWhite LEDs (Series: MTGEZW)

This LM-80 report is applicable to the following order codes:

MT-G 6 V: MTGEZW-xx-xxxx-xBxxxxxxx
MT-G 36 V: MTGEZW-xx-xxxx-xNxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	55 °C	55 °C	2000 mA (6 V) 333 mA (36 V)	2700 K	25	6,048 hrs	L90(6k) = 25,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	85 °C	85 °C	2000 mA (6 V) 333 mA (36 V)	2700 K	25	6,048 hrs	L90(6k) = 15,900 hrs L80(6k) = 35,000 hrs L70(6k) > 36,300 hrs
3	105 °C	105 °C	2000 mA (6 V) 333 mA (36 V)	2700 K	25	6,048 hrs	L90(6k) = 14,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4	55 °C	55 °C	3000 mA (6 V) 500 mA (36 V)	3000 K	25	6,048 hrs	L90(6k) = 23,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	85 °C	85 °C	3000 mA (6 V) 500 mA (36 V)	3000 K	25	6,048 hrs	L90(6k) = 13,200 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
6	105 °C	105 °C	3000 mA (6 V) 500 mA (36 V)	3000 K	25	6,048 hrs	L90(6k) = 11,800 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
7	105 °C	105 °C	4200 mA (6 V) 700 mA (36 V)	3000 K	25	6,048 hrs	L90(6k) = 14,000 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® MT-G2 EASYWHITE® LEDS (REV 3)

Revision: 3 (June 15, 2014)

# **Description Of LED Light Sources**

XLamp MT-G2 EasyWhite LEDs (Series: MTGBEZ)

This LM-80 report is applicable to the following order codes:

MT-G2 6 V: MTGBEZ-xx-xxxx-xBxxxxxxx
MT-G2 9V: MTGBEZ-xx-xxxx-xCxxxxxxx
MT-G2 36 V: MTGBZW-xx-xxxx-xNxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	3000 mA (6 V) 2000 mA (9 V) 500 mA (36 V)	3000 K	25	6,048 hrs	L90(6k) = 12,000 hrs L80(6k) = 26,600 hrs L70(6k) > 36,300 hrs
1+	85 °C	85 °C	3000 mA (6 V) 2000 mA (9 V) 500 mA (36 V)	3000 K	15	13,104 hrs	L90(13k) = 22,300 hrs L80(13k) = 59,200 hrs L70(13k) > 78,600 hrs
2	105 °C	105 °C	3000 mA (6 V) 2000 mA (9 V) 500 mA (36 V)	3000 K	26	6,048 hrs	L90(6k) = 6,060 hrs L80(6k) = 15,400 hrs L70(6k) = 26,000 hrs
2+	105 °C	105 °C	3000 mA (6 V) 2000 mA (9 V) 500 mA (36 V)	3000 K	20	7,056 hrs	L70(7k) = 27,700 hrs



#### XLAMP® MX-3 WHITE LEDS (REV 0)

Revision: 0 (March 29, 2011)

## **Description Of LED Light Sources**

XLamp MX-3 White LEDs (Parallel (MX3AWT) & Series (MX3SWT) Configurations)

This LM-80 report is applicable to the following order codes:

MX-3 Parallel: MX3AWT-xx-xxxx-xxxxx MX-3 Series: MX3SWT-xx-xxxx-xxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	45 °C	45 °C	400 mA (MX3AWT) 133 mA (MX3SWT)	2700 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	55 °C	55 °C	400 mA (MX3AWT) 133 mA (MX3SWT)	2700 K	25	6,048 hrs	L90(6k) = 21,700 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	85 °C	85 °C	400 mA (MX3AWT) 133 mA (MX3SWT)	2700 K	25	6,048 hrs	L90(6k) = 16,600 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® MX-6 WHITE LEDS (REV 2)

Revision: 2 (September 2, 2011)

#### **Description Of LED Light Sources**

XLamp MX-6 White LEDs (Parallel (MX6AWT) & Series (MX6SWT) Configurations)

This LM-80 report is applicable to the following order codes:

MX-6 Parallel: MX6AWT-xx-xxxx-xxxxx MX-6 Series: MX6SWT-xx-xxxx-xxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	45 °C	45 °C	350 mA (MX6AWT) 58 mA (MX6SWT)	2700 K	26	6,048 hrs	L90(6k) = 15,700 hrs L80(6k) = 29,400 hrs L70(6k) > 36,300 hrs
2	55 °C	55 °C	350 mA (MX6AWT) 58 mA (MX6SWT)	2700 K	28	6,048 hrs	L90(6k) = 27,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	85 °C	85 °C	350 mA (MX6AWT) 58 mA (MX6SWT)	3000 K	30	6,048 hrs	L90(6k) = 12,100 hrs L80(6k) = 23,100 hrs L70(6k) = 35,600 hrs
4	45 °C	45 °C	600 mA (MX6AWT) 100 mA (MX6SWT)	2700 K	25	6,048 hrs	L90(6k) = 28,400 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	55 °C	55 °C	600 mA (MX6AWT) 100 mA (MX6SWT)	2700 K	25	6,048 hrs	L90(6k) = 19,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
6	85 °C	85 °C	600 mA (MX6AWT) 100 mA (MX6SWT)	2700 K	25	6,048 hrs	L90(6k) = 11,100 hrs L80(6k) = 22,000 hrs L70(6k) = 34,400 hrs



#### XLAMP® XB-D WHITE LEDS (REV 2)

Revision: 2 (October 10, 2013)

**Description Of LED Light Sources** 

XLamp XB-D White LEDs (Series: XBDAWT)

This LM-80 report is applicable to the following order codes:

XBDAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
7	85 °C	85 °C	500 mA	3000 K	25	10,080 hrs	L95(10k) = 29,400 hrs L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
3	105 °C	105 °C	700 mA	3000 K	25	10,080 hrs	L90(10k) = 56,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
4	55 °C	55 °C	1000 mA	3000 K	25	10,080 hrs	L90(10k) = 45,000 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	85 °C	85 °C	1000 mA	3000 K	24	10,080 hrs	L90(10k) = 33,400 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
6	105 °C	105 °C	1000 mA	3000 K	25	6,048 hrs	L90(6k) = 12,800 hrs L80(6k) = 29,100 hrs L70(6k) > 36,300 hrs



#### XLAMP® XB-E HIGH VOLTAGE WHITE LEDS (REV 0)

Revision: 0 (October 11, 2013)

**Description Of LED Light Sources** 

XLamp XB-E White LEDs (Series: XBEHVW)

This LM-80 report is applicable to the following order codes:

XBEHVW-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	105 °C	105 °C	44 mA	2700 K	25	6,048 hrs	L90(6k) = 10,400 hrs L80(6k) = 23,100 hrs L70(6k) > 36,300 hrs



#### XLAMP® XB-G HIGH VOLTAGE WHITE LEDS (REV 1)

Revision: 1 (March 4, 2014)

**Description Of LED Light Sources** 

XLamp XB-G White LEDs (Series: XBGHVW)

This LM-80 report is applicable to the following order codes:

XBGHVW-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	105 °C	105 °C	44 mA	2700 K	25	6,048 hrs	L90(6k) = 17,800 hrs L80(6k) = 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XB-H WHITE LEDS (REV 1)

Revision: 1 (January 5, 2015)

**Description Of LED Light Sources** 

XLamp XB-H White LEDs (Series: XBHAWT)

This LM-80 report is applicable to the following order codes:

XBHAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	105 °C	105 °C	700 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4	85 °C	85 °C	1000 mA	3000 K	25	6,048 hrs	L90(6k) = 35,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	105 °C	105 °C	1000 mA	3000 K	25	6,048 hrs	L90(6k) = 35,100 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	85 °C	85 °C	1500 mA	3000 K	25	6,048 hrs	L90(6k) = 28,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XH-B WHITE LEDS (REV 3)

Revision: 3 (October 20, 2016)

**Description Of LED Light Sources** 

XLamp XH-B White LEDs (Series: XHBAWT)

This LM-80 report is applicable to the following order codes:

XHBAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	80 mA	3000 K	25	14,112 hrs	L90(14k) = 70,100 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
2	105 °C	105 °C	80 mA	3000 K	25	6,552 hrs	L90(7k) > 39,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs
2+	105 °C	105 °C	80 mA	3000 K	24	14,112 hrs	L90(14k) = 45,100 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
4	85 °C	85 °C	125 mA	3000 K	25	23,184 hrs	L90(23k) > 139,000 hrs L80(23k) > 139,000 hrs L70(23k) > 139,000 hrs
5	105 °C	105 °C	125 mA	3000 K	25	23,184 hrs	L90(23k) = 44,100 hrs L80(23k) = 119,000 hrs L70(23k) > 139,000 hrs



#### XLAMP® XH-G WHITE LEDS (REV 3)

Revision: 3 (May 13, 2015)

## **Description Of LED Light Sources**

XLamp XH-G White LEDs (Series: XHGAWT)

This LM-80 report is applicable to the following order codes:

XHGAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	80 mA	3000 K	25	14,616 hrs	L90(15k) = 77,500 hrs L80(15k) > 87,700 hrs L70(15k) > 87,700 hrs
2	105 °C	105 °C	80 mA	3000 K	15	14,112 hrs	L90(14k) > 77,600 hrs L80(14k) > 77,600 hrs L70(14k) > 77,600 hrs
3	85 °C	85 °C	175 mA	3000 K	25	14,112 hrs	L90(14k) = 56,600 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
4	105 °C	105 °C	175 mA	3000 K	25	14,112 hrs	L90(14k) = 30,500 hrs L80(14k) = 66,000 hrs L70(14k) > 84,700 hrs
5	85 °C	85 °C	350 mA	3000 K	25	6,552 hrs	L90(7k) = 24,300 hrs L80(7k) > 39,300 hrs L70(7k) > 39,300 hrs



#### XLAMP® XHP35 WHITE LEDS (REV 4)

Revision: 4 (March 8, 2017)

## **Description Of LED Light Sources**

XLamp XHP35 White LEDs (Series: XHP35A)

This LM-80 report is applicable to the following order codes:

XHP35A-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
4	85 °C	85 °C	350 mA	3000 K	25	7,056 hrs	L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
4+	85 °C	85 °C	350 mA	3000 K	23	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	105 °C	105 °C	350 mA	3000 K	25	9,576 hrs	L90(10k) = 38,800 hrs L80(10k) > 57,500 hrs L70(10k) > 57,500 hrs
5+	105 °C	105 °C	350 mA	3000 K	22	10,080 hrs	L90(10k) = 37,700 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
6	125 °C	125 °C	350 mA	3000 K	20	9,072 hrs	L90(9k) = 26,300 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
7	85 °C	85 °C	525 mA	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
8	105 °C	105 °C	525 mA	3000 K	25	10,080 hrs	L90(10k) = 26,000 hrs L80(10k) > 55,100 hrs L70(10k) > 60,500 hrs
9	125 °C	125 °C	525 mA	3000 K	20	6,048 hrs	L90(6k) = 16,000 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
1	85 °C	85 °C	700 mA	3000 K	24	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
2	105 °C	105 °C	700 mA	3000 K	25	9,072 hrs	L90(9k) = 38,900 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
3	85 °C	85 °C	1050 mA	3000 K	21	8,568 hrs	L90(9k) = 33,200 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
10	105 °C	105 °C	1050 mA	3000 K	25	6,048 hrs	L90(6k) = 24,700 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XHP50 WHITE LEDS (REV 4)

Revision: 4 (February 15, 2017)

## **Description Of LED Light Sources**

XLamp XHP50 White LEDs (Series: XHP50A)

This LM-80 report is applicable to the following order codes:

XHP50A-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
XHP50-3	85 °C	85 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	24	14,112 hrs	L90(14k) > 84,700 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
XHP50-4	105 °C	105 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	25	12,096 hrs	L90(12k) = 56,700 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
XHP50-5	125 °C	125 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	20	10,080 hrs	L90(10k) = 21,700 hrs L80(10k) = 52,900 hrs L70(10k) > 60,500 hrs
XHP50-6	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
XHP50-6+	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	24	14,112 hrs	L90(14k) > 84,700 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
XHP50-7	105 °C	105 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
XHP50-8	85 °C	85 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	25	6,048 hrs	L90(6k) = 29,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
XHP50-8+	85 °C	85 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	23	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs



#### XLAMP® XHP50.2 WHITE LEDS (REV 0)

Revision: 0 (March 6, 2017)

## **Description Of LED Light Sources**

XLamp XHP50.2 White LEDs (Series: XHP50B)

This LM-80 report is applicable to the following order codes:

XHP50B-xx-xxxx-xxxxxxxx

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
XHP50-3	85 °C	85 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	24	14,112 hrs	L90(14k) > 84,700 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
XHP50-4	105 °C	105 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	25	12,096 hrs	L90(12k) = 56,700 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
XHP50-5	125 °C	125 °C	1400 mA (6 V) 700 mA (12 V)	3000 K	20	10,080 hrs	L90(10k) = 21,700 hrs L80(10k) = 52,900 hrs L70(10k) > 60,500 hrs
XHP50-6	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
XHP50-6+	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	24	14,112 hrs	L90(14k) > 84,700 hrs L80(14k) > 84,700 hrs L70(14k) > 84,700 hrs
XHP50-7	105 °C	105 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
XHP50-8	85 °C	85 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	25	6,048 hrs	L90(6k) = 29,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
XHP50-8+	85 °C	85 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	23	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs

#### **Scaling For Applicable Products**

The data sets cited below meet all the criteria for one LM-80 data set to apply to a range of LED arrays, as defined in the ENERGY STAR September 9, 2011 guidelines, Section 3.7.d. The table below defines the current values that apply to each product when scaled from the tested LM-80 products. The tested product is listed in bold text below.



#### XLAMP® XHP50.2 WHITE LEDS (REV 0) - CONTINUED

				Applicable Currents							
Product Name	Voltage Class	Product Order Code	Data Set XHP50-3 (85 °C)	Data Set XHP50-4 (105 °C)	Data Set XHP50-5 (125 °C)	Data Set XHP50-6, XHP50-6+ (85°C)	Data Set XHP50-7 (105 °C)	Data Set XHP50-8, XHP50-8+ (85°C)			
XHP50.2	6 V	XHP50B-xx-xxxx-xxxxxxxx	1400 mA	1400 mA	1400 mA	2100 mA	2100 mA	3000 mA			
XHP50.2	12 V	XHP50B-xx-xxxx-xxxxxxxx	700 mA	700 mA	700 mA	1050 mA	1050 mA	1500 mA			
XHP50	12 V	XHP50A-xx-xxxx-xxxxxxxxx	700 mA	700 mA	700 mA	1050 mA	1050 mA	1500 mA			



#### XLAMP® XHP70 WHITE LEDS (REV 6)

Revision: 6 (April 14, 2016)

## **Description Of LED Light Sources**

XLamp XHP70 White LEDs (Series: XHP70A)

This LM-80 report is applicable to the following order codes:

XHP70A-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
4	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	11,592 hrs	L90(12k) > 69,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs
4+	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	15,120 hrs	L90(15k) > 90,700 hrs L80(15k) > 90,700 hrs L70(15k) > 90,700 hrs
1	105 °C	105 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	20	8,064 hrs	L90(8k) > 48,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
1+	105 °C	105 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	16	13,104 hrs	L90(13k) > 72,100 hrs L80(13k) > 72,100 hrs L70(13k) > 72,100 hrs
2	125 °C	125 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	20	8,568 hrs	L90(9k) > 51,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
5	85 °C	85 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	25	15,624 hrs	L90(16k) > 93,700 hrs L80(16k) > 93,700 hrs L70(16k) > 93,700 hrs
3	105 °C	105 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	20	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
3+	105 °C	105 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	17	14,616 hrs	L90(15k) = 39,300 hrs L80(15k) > 80,400 hrs L70(15k) > 80,400 hrs
6	85 °C	85 °C	4200 mA (6 V) 2100 mA (12 V)	3000 K	25	14,616 hrs	L90(15k) > 87,700 hrs L80(15k) > 87,700 hrs L70(15k) > 87,700 hrs
7	105 °C	105°C	4200 mA (6 V) 2100 mA (12 V)	3000 K	25	10,584 hrs	L90(11k) = 52,400 hrs L80(11k) > 63,500 hrs L70(11k) > 63,500 hrs
8	85 °C	85 °C	4800 mA (6 V) 2400 mA (12 V)	3000 K	20	11,592 hrs	L90(12k) > 69,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs



#### XLAMP® XHP70.2 WHITE LEDS (REV 0)

Revision: 0 (June 20, 2017)

## **Description Of LED Light Sources**

XLamp XHP70 White LEDs (Series: XHP70B)

This LM-80 report is applicable to the following order codes:

XHP70B-xx-xxxx-xxxxxxxx

No failures occurred during testing.

#### **Results Summary For Tested LED Array**

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. $[T_{\underline{a}}]$	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
XHP70-4	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	11,592 hrs	L90(12k) > 69,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs
XHP70-4+	85 °C	85 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	25	15,120 hrs	L90(15k) > 90,700 hrs L80(15k) > 90,700 hrs L70(15k) > 90,700 hrs
XHP70-1	105 °C	105 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	20	8,064 hrs	L90(8k) > 48,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
XHP70-1+	105 °C	105 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	16	13,104 hrs	L90(13k) > 72,100 hrs L80(13k) > 72,100 hrs L70(13k) > 72,100 hrs
XHP70-2	125 °C	125 °C	2100 mA (6 V) 1050 mA (12 V)	3000 K	20	8,568 hrs	L90(9k) > 51,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
XHP70-5	85 °C	85 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	25	15,624 hrs	L90(16k) > 93,700 hrs L80(16k) > 93,700 hrs L70(16k) > 93,700 hrs
XHP70-3	105°C	105 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	20	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
XHP70-3+	105°C	105 °C	3000 mA (6 V) 1500 mA (12 V)	3000 K	17	14,616 hrs	L90(15k) = 39,300 hrs L80(15k) > 80,400 hrs L70(15k) > 80,400 hrs
XHP70-6	85 °C	85 °C	4200 mA (6 V) 2100 mA (12 V)	3000 K	25	14,616 hrs	L90(15k) > 87,700 hrs L80(15k) > 87,700 hrs L70(15k) > 87,700 hrs
XHP70-7	105 °C	105 °C	4200 mA (6 V) 2100 mA (12 V)	3000 K	25	10,584 hrs	L90(11k) = 52,400 hrs L80(11k) > 63,500 hrs L70(11k) > 63,500 hrs
XHP70-8	85 °C	85 °C	4800 mA (6 V) 2400 mA (12 V)	3000 K	20	11,592 hrs	L90(12k) > 69,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs



#### XLAMP® XHP70.2 WHITE LEDS (REV 0) - CONTINUED

#### **Scaling For Applicable Products**

The data sets cited below meet all the criteria for one LM-80 data set to apply to a range of LED arrays, as defined in the ENERGY STAR September 9, 2011 guidelines, Section 3.7.d. The table below defines the current values that apply to each product when scaled from the tested LM-80 products. The tested product is listed in bold text below.

			Applicable Currents			
Product Name	Voltage Class	Product Order Code	Data Set XHP70-4, XHP70-4+ (85 °C)	Data Set XHP70-1, XHP70-1+ (105°C)	Data Set XHP70-2 (125°C)	
XHP70.2	6 V	XHP70B-xx-xxxx-xxxxxxxx	2100 mA	2100mA	2100 mA	
XHP70.2	12 V	XHP70B-xx-xxxx-xxxxxxxx	1050mA	1050 mA	1050 mA	
XHP70	12 V	XHP70A-xx-xxxx-xxxxxxxx	1050 mA	1050 mA	1050 mA	

			Applicable Currents				
Product Name	Voltage Class	Product Order Code	Data Set XHP70-5 (85°C)	Data Set XHP70-3, XHP70-3+ (105°C)	Data Set XHP70-6 (85°C)		
XHP70.2	6 V	XHP70B-xx-xxxx-xxxxxxxx	3000 mA	3000mA	4200 mA		
XHP70.2	12 V	XHP70B-xx-xxxx-xxxxxxxx	1500 mA	1500 mA	2100 mA		
XHP70	12 V	XHP70A-xx-xxxx-xxxxxxxx	1500 mA	1500 mA	2100 mA		

			Applicable Currents			
Product Name	Voltage Class	Product Order Code	Data Set XHP70-7 (105°C)	Data Set XHP70-8 (85°C)		
XHP70.2	6 V	XHP70B-xx-xxxx-xxxxxxxx	4200 mA	4800 mA		
XHP70.2	12 V	XHP70B-xx-xxxx-xxxxxxxx	2100mA	2400mA		
XHP70	12 V	XHP70A-xx-xxxx-xxxxxxxx	2100 mA	2400 mA		



#### XLAMP® XM-L EASYWHITE® LEDS (REV 1)

Revision: 1 (August 8, 2013)

## **Description Of LED Light Sources**

XLamp XM-L EasyWhite LEDs (Series: XMLEZW)

This LM-80 report is applicable to the following order codes:

XM-L EZW 6 V: XMLEZW-xx-xxxx-xBxxxxxxx XM-L EZW 12 V: XMLEZW-xx-xxxx-xDxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3	105°C	105 °C	700 mA (6 V) 350 mA (12 V)	2700 K	25	15,120 hrs	L95(15k) = 28,700 hrs L90(15k) > 90,700 hrs L80(15k) > 90,700 hrs L70(15k) > 90,700 hrs
6	105°C	105 °C	1000 mA (6 V) 500 mA (12 V)	3000 K	25	7,056 hrs	L95(7k) = 42,200 hrs L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
7	85 °C	85 °C	1500 mA (6 V) 750 mA (12 V)	3000 K	25	6,048 hrs	L95(6k) = 19,400 hrs L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XM-L HIGH VOLTAGE WHITE LEDS (REV 0)

Revision: 0 (November 13, 2012)

#### **Description Of LED Light Sources**

XLamp XM-L High Voltage White LEDs (Series: XMLHVW)

This LM-80 report is applicable to the following order codes:

XMLHVW-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	55 °C	55 °C	88 mA	3000 K	25	6,048 hrs	L90(6k) = 15,000 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	85 °C	85 °C	88 mA	3000 K	25	6,048 hrs	L90(6k) = 8,180 hrs L80(6k) = 22,100 hrs L70(6k) > 36,300 hrs
3	105 °C	105 °C	88 mA	3000 K	25	6,048 hrs	L90(6k) = 7,450 hrs L80(6k) = 19,500 hrs L70(6k) = 33,200 hrs



#### XLAMP® XM-L WHITE LEDS (REV 2)

Revision: 2 (October 31, 2012)

# **Description Of LED Light Sources**

XLamp XM-L White LEDs (Series: XMLAWT)

This LM-80 report is applicable to the following order codes:

XMLAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
4	55 °C	55 °C	1500 mA	2700 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	85 °C	85 °C	1500 mA	2700 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5+	85 °C	85 °C	1500 mA	2700 K	23	12,096 hrs	L90(12k) = 29,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
6	105 °C	105 °C	1500 mA	2700 K	25	10,080 hrs	L90(10k) = 27,700 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
6+	105 °C	105 °C	1500 mA	2700 K	23	12,096 hrs	L90(12k) = 25,900 hrs L80(12k) = 59,800 hrs L70(12k) > 72,600 hrs
7	55 °C	55 °C	2000 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
7+	55 °C	55 °C	2000 mA	3000 K	11	11,088 hrs	L90(11k) > 61,000 hrs L80(11k) > 61,000 hrs L70(11k) > 61,000 hrs
8	85 °C	85 °C	2000 mA	3000 K	25	9,072 hrs	L90(9k) = 38,300 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
8+	85 °C	85 °C	2000 mA	3000 K	21	12,096 hrs	L90(12k) = 24,800 hrs L80(12k) = 52,600 hrs L70(12k) > 72,600 hrs
9	105 °C	105 °C	2000 mA	3000 K	25	6,048 hrs	L90(6k) = 21,600 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
9+	105 °C	105 °C	2000 mA	3000 K	14	8,568 hrs	L90(9k) = 15,900 hrs L80(9k) = 33,700 hrs L70(9k) > 47,100 hrs
10	85 °C	85 °C	3000 mA	3000 K	25	6,048 hrs	L90(6k) = 11,100 hrs L80(6k) = 25,000 hrs L70(6k) > 36,300 hrs



#### XLAMP® XM-L2 WHITE LEDS (REV 3B)

Revision: 3B (March 23, 2015)

## **Description Of LED Light Sources**

XLamp XM-L2 White LEDs (Series: XMLBWT)

This LM-80 report is applicable to the following order codes:

XMLBWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>a</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	1500 mA	2700 K	25	7,560 hrs	L95(8k) > 45,400 hrs L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
1+	85 °C	85 °C	1500 mA	2700 K	23	12,096 hrs	L95(12k) = 30,100 hrs L90(12k) = 60,900 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
2	105 °C	105 °C	1500 mA	2700 K	25	8,568 hrs	L95(9k) = 19,600 hrs L90(9k) = 43,900 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
8	55 °C	55 °C	2100 mA	2700 K	25	9,072 hrs	L95(9k) > 54,400 hrs L90(9k) >54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
8+	55 °C	55 °C	2100 mA	2700 K	17	12,096 hrs	L95(12k) > 66,500 hrs L90(12k) > 66,500 hrs L80(12k) > 66,500 hrs L70(12k) > 66,500 hrs
10	105°C	105 °C	2100 mA	3000 K	25	6,048 hrs	L95(6k) = 14,900 hrs L90(6k) > 36,600 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
9	55 °C	55 °C	3000 mA	2700 K	25	6,048 hrs	L95(6k) = 16,800 hrs L90(6k) = 35,600 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
11	85 °C	85 °C	3000 mA	3000 K	25	6,048 hrs	L95(6k) = 7,950 hrs L90(6k) = 17,100 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XP-E HIGH EFFICIENCY WHITE LEDS (REV 4)

Revision: 4 (April 25, 2012)

## **Description Of LED Light Sources**

XLamp XP-E High Efficiency White LEDs (Series: XPEHEW)

This LM-80 report is applicable to the following order codes:

XPEHEW-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
11	85 °C	85 °C	350 mA	3000 K	25	10,080 hrs	L90(10k) = 32,800 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
12	105 °C	105 °C	350 mA	3000 K	25	6,048 hrs	L90(6k) = 15,600 hrs L70(6k) = 34,100 hrs L70(6k) > 36,300 hrs
8	55 °C	55 °C	500 mA	2700 K	25	8,064 hrs	L90(8k) > 48,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
9	85 °C	85 °C	500 mA	2700 K	25	8,064 hrs	L90(8k) = 28,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
10	85 °C	85 °C	700 mA	3000 K	25	9,072 hrs	L90(9k) = 21,900 hrs L80(9k) = 44,100 hrs L70(9k) > 54,400 hrs



#### XLAMP® XP-E WHITE LEDS (REV 3)

Revision: 3 (November 9, 2011)

## **Description Of LED Light Sources**

XLamp XP-E White LEDs (Series: XPEWHT)

This LM-80 report is applicable to the following order codes:

XPEWHT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
8	55 °C	55 °C	350 mA	2700 K	25	10,080 hrs	L90(10k) = 56,800 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
9	85 °C	85 °C	350 mA	2700 K	25	10,080 hrs	L90(10k) = 39,700 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
10	105 °C	105 °C	350 mA	2700 K	25	6,048 hrs	L90(6k) = 19,400 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	45 °C	45 °C	700 mA	2700 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
6	55 °C	55 °C	700 mA	2700 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
7	85 °C	85 °C	700 mA	2700 K	25	10,080 hrs	L90(10k) = 28,300 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs



#### XLAMP® XP-E2 RED, RED-ORANGE, AMBER, PHOSPHOR-CONVERTED AMBER, GREEN & BLUE LEDS (REV 2)

Revision: 2 (April 26, 2016)

## **Description Of LED Light Sources**

XLamp XP-E2 Red LEDs (Series: XPEBRD)

XLamp XP-E2 Red-Orange LEDs (Series: XPEBRO)

XLamp XP-E2 Amber LEDs (Series: XPEBAM)

XLamp XP-E2 Phosphor-Converted Amber LEDs (Series: XPEBPA)

XLamp XP-E2 Green LEDs (Series: XPEBGR) XLamp XP-E2 Blue LEDs (Series: XPEBBL)

This LM-80 report is applicable to the following order codes:

XPEBRD-xx-xxxx-xxxxx

XPEBRO-xx-xxxx-xxxxx

XPEBAM-xx-xxxx-xxxxx

XPEBPA-xx-xxxx-xxxxx

XPEBGR-xx-xxxx-xxxxx

XPEBBL-xx-xxxx-xxxxx

No failures occurred during testing.

LED Color	Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current	Sample Count	Test Duration	Reported TM-21 Lifetimes
Red,	R3	85 °C	85 °C	1000 mA	20	17,136 hrs	L90(17k) = 68,900 hrs L80(17k) > 103,000 hrs L70(17k) > 103,000 hrs
Red-Orange	R2	105 °C	105 °C	1000 mA	25	12,096 hrs	L90(12k) = 55,700 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
Amber	A1	85 °C	85 °C	1000 mA	14	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
Ambei	A2	105 °C	105 °C	1000 mA	13	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
Phosphor- Converted Amber	PCA1	85 °C	85 °C	1000 mA	20	11,592 hrs	L90(12k) = 13,200 hrs L80(12k) = 30,900 hrs L70(12k) = 51,000 hrs
	PCA2	105 °C	105 °C	1000 mA	19	6,048 hrs	L90(6k) = 10,700 hrs L80(6k) = 21,800 hrs L70(6k) = 34,400 hrs



# XLAMP® XP-E2 RED, RED-ORANGE, AMBER, PHOSPHOR-CONVERTED AMBER, GREEN & BLUE LEDS (REV 2) - CONTINUED

LED Color	Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	Sample Count	Test Duration	Reported TM-21 Lifetimes
Green	G2	105 °C	105 °C	500 mA	20	8,568 hrs	L90(9k) > 51,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
	G3	85 °C	85 °C	1000 mA	20	8,568 hrs	L90(9k) > 51,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
Blue	B2	105 °C	105 °C	500 mA	20	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
	В3	85 °C	85 °C	1000 mA	20	8,568 hrs	L90(9k) > 51,400 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs



#### XLAMP® XP-E2 WHITE LEDS (REV 1)

Revision: 1 (February 25, 2014)

## **Description Of LED Light Sources**

XLamp XP-E2 White LEDs (Series: XPEBWT)

This LM-80 report is applicable to the following order codes:

XPEBWT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3	85 °C	85 °C	350 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3+	85 °C	85 °C	350 mA	3000 K	18	9,072 hrs	L90(9k) > 49,900 hrs L80(9k) > 49,900 hrs L70(9k) > 49,900 hrs
1	105 °C	105 °C	350 mA	3000 K	25	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
4	55 °C	55 °C	700 mA	3000 K	25	7,056 hrs	L90(7k) > 42,300 hrs L80(7k) > 42,300 hrs L70(7k) > 42,300 hrs
2	85 °C	85 °C	700 mA	3000 K	25	7,056 hrs	L90(7k) = 18,300 hrs L80(7k) = 37,100 hrs L70(7k) > 42,300 hrs
5	105 °C	105 °C	700 mA	3000 K	25	6,048 hrs	L90(6k) = 17,100 hrs L80(6k) = 35,900 hrs L70(6k) > 36,300 hrs



#### XLAMP® XP-G WHITE LEDS (REV 7)

Revision: 7 (March 18, 2014)

## **Description Of LED Light Sources**

XLamp XP-G White LEDs (Series: XPGWHT)

This LM-80 report is applicable to the following order codes:

XPGWHT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
17	55 °C	55 °C	1000 mA	3000 K	25	6,048 hrs	L95(6k) > 36,300 hrs L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
13	85 °C	85 °C	1000 mA	3000 K	25	13,608 hrs	L95(14k) > 81,600 hrs L90(14k) > 81,600 hrs L80(14k) > 81,600 hrs L70(14k) > 81,600 hrs
14	105 °C	105 °C	1000 mA	3000 K	25	12,096 hrs	L95(12k) > 72,600 hrs L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
15	55 °C	55 °C	1500 mA	3000 K	25	12,096 hrs	L95(12k) > 72,600 hrs L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
16	85 °C	85 °C	1500 mA	3000 K	25	12,096 hrs	L95(12k) > 72,600 hrs L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs



#### XLAMP® XP-G2 WHITE LEDS (REV 8)

Revision: 8 (January 6, 2016)

## **Description Of LED Light Sources**

XLamp XP-G2 White LEDs (Series: XPGBWT)

This LM-80 report is applicable to the following order codes:

XPGBWT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
11	125 °C	125 °C	350 mA	3000 K	25	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
9	85 °C	85 °C	500 mA	3000 K	25	10,584 hrs	L90(11k) > 63,500 hrs L80(11k) > 63,500 hrs L70(11k) > 63,500 hrs
9+	85 °C	85 °C	500 mA	3000 K	20	13,608 hrs	L90(14k) > 81,600 hrs L80(14k) > 81,600 hrs L70(14k) > 81,600 hrs
10	105 °C	105 °C	500 mA	3000 K	25	11,088 hrs	L90(11k) > 66,500 hrs L80(11k) > 66,500 hrs L70(11k) > 66,500 hrs
10+	105 °C	105 °C	500 mA	3000 K	19	14,112 hrs	L90(14k) > 77,600 hrs L80(14k) > 77,600 hrs L70(14k) > 77,600 hrs
15	105° C	105 °C	700 mA	3000 K	20	8,568 hrs	L90(8.5k) > 51,400 hrs L80(8.5k) > 51,400 hrs L70(8.5k) > 51,400 hrs
3	55 °C	55 °C	1000 mA	3000 K	25	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
3+	55 °C	55 °C	1000 mA	3000 K	20	10,080 hrs	L90(10k) = 49,700 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
16	85° C	85 °C	1000 mA	4000 K	20	8,568 hrs	L90(8.5k) > 51,400 hrs L80(8.5k) > 51,400 hrs L70(8.5k) > 51,400 hrs
17	85° C	85 °C	1000 mA	3000 K	20	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
18	105 °C	105 °C	1000 mA	3000 K	20	8,568 hrs	L90(8.5k) > 51,400 hrs L80(8.5k) > 51,400 hrs L70(8.5k) > 51,400 hrs
13	55 °C	55 °C	1500 mA	3000 K	25	7,560 hrs	L90(7.5k) = 36,400 hrs L80(7.5k) > 45,400 hrs L70(7.5k) > 45,400 hrs



#### XLAMP® XP-G2 WHITE LEDS (REV 8) - CONTINUED

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
7	85 °C	85 °C	1500 mA	3000 K	25	6,048 hrs	L90(6k) = 24,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XP-G3 WHITE LEDS (REV 7)

Revision: 7 (May 15, 2017)

### **Description Of LED Light Sources**

XLamp XP-G3 White LEDs (Series: XPGDWT)

This LM-80 report is applicable to the following order codes:

XPGDWT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3	85 °C	85 °C	350 mA	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
4	105 °C	105 °C	350 mA	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	120 °C	120 °C	350 mA	3000 K	25	6,048 hrs	L90(6k) = 14,300 hrs L80(6k) = 33,000 hrs L70(6k) > 36,300 hrs
6	85 °C	85 °C	700 mA	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
7	105 °C	105 °C	700 mA	3000 K	25	10,080 hrs	L90(10k) = 46,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
8	120 °C	120 °C	700 mA	3000 K	25	6,048 hrs	L90(6k) = 11,200 hrs L80(6k) = 27,500 hrs L70(6k) > 36,300 hrs
9	85 °C	85 °C	1050 mA	3000 K	25	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
10	105 °C	105 °C	1050 mA	4000 K	20	6,048 hrs	L90(6k) = 20,200 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
11	85 °C	85 °C	1500 mA	3000 K	25	10,080 hrs	L90(10k) > 33,600 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
14	105 °C	105 °C	1500 mA	3000 K	23	10,080 hrs	L90(10k) = 27,900 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
12	120° C	120 °C	1500 mA	3000 K	20	6,048 hrs	L90(6k) = 7,830 hrs L80(6k) = 20,800 hrs L70(6k) = 35,500 hrs
13	85 °C	85 °C	2000 mA	3000 K	25	6,048 hrs	L90(6k) = 17,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XP-L WHITE LEDS (REV 7)

Revision: 7 (September 20, 2016)

### **Description Of LED Light Sources**

XLamp XP-L White LEDs (Series: XPLAWT)

This LM-80 report is applicable to the following order codes:

XPLAWT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F.</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
6	105 °C	105 °C	1050 mA	3000 K	20	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	85 °C	85 °C	1500 mA	3000 K	20	12,096 hrs	L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
3	105 °C	105 °C	1500 mA	3000 K	25	11,592 hrs	L90(12k) = 66,600 hrs L80(12k) > 69,600 hrs L70(12k) > 69,600 hrs
4	85 °C	85 °C	2100 mA	3000 K	25	10,080 hrs	L90(10k) = 42,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
1	105 °C	105 °C	2100 mA	3000 K	25	6,048 hrs	L90(6k) = 24,000 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	85 °C	85 °C	3000 mA	3000 K	25	6,048 hrs	L90(6k) = 16,300 hrs L80(6k) = 35,800 hrs L70(6k) > 36,300 hrs



#### XLAMP® XP-L2 WHITE LEDS (REV 3)

Revision: 3 (June 1, 2017)

### **Description Of LED Light Sources**

XLamp XP-L2 White LEDs (Series: XPLBWT)

This LM-80 report is applicable to the following order codes:

XPLBWT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
4	85 °C	85 °C	1500 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	105 °C	105 °C	1500 mA	3000 K	25	6,048 hrs	L90(6k) = 28,100 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	85 °C	85 °C	2100 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XQ-A RED, RED-ORANGE, PHOSPHOR-CONVERTED AMBER, GREEN, BLUE & ROYAL BLUE LEDS (REV 0)

Revision: 0 (September 16, 2016)

### **Description Of LED Light Sources**

XLamp XQ-A Red LEDs (Series: XQARED)

XLamp XQ-A Red-Orange LEDs (Series: XQARDO)

XLamp XQ-A Phosphor-Converted Amber LEDs (Series: XQAAPA)

XLamp XQ-A Green LEDs (Series: XQAGRN) XLamp XQ-A Blue LEDs (Series: XQABLU)

XLamp XQ-A Royal Blue LEDs (Series: XQAROY)

This LM-80 report is applicable to the following order codes:

XQARED-xx-xxxx-xxxxxxxx

XQARDO-xx-xxxx-xxxxxxxx

XQAAPA-xx-xxxx-xxxxxxxx

XQAGRN-xx-xxxx-xxxxxxxx

XQABLU-xx-xxxx-xxxxxxxx

XQAROY-xx-xxxx-xxxxxxxx

No failures occurred during testing.

LED Color	Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	Sample Count	Test Duration	Reported TM-21 Lifetimes
Red, Red-Orange	R1	105 °C	105 °C	250 mA	20	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
Phosphor- Converted Amber	PCA1	105 °C	105 °C	250 mA	20	6,048 hrs	L90(6k) = 28,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
Green	G1	85 °C	85 °C	250 mA	20	6,048 hrs	L90(6k) = 5,400 hrs L80(6k) = 19,100 hrs L70(6k) = 34,500 hrs
Green	G2	105 °C	105 °C	250 mA	20	6,048 hrs	L90(6k) = 990 hrs L80(6k) = 9,490 hrs L70(6k) = 20,400 hrs
Pluo	B1	85 °C	85 °C	250 mA	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
Blue	B2	105 °C	105 °C	250 mA	10	6,048 hrs	L90(6k) = 24,800 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs



# XLAMP® XQ-A RED, RED-ORANGE, PHOSPHOR-CONVERTED AMBER, GREEN, BLUE & ROYAL BLUE LEDS (REV 0) - CONTINUED

LED Color	Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	Sample Count	Test Duration	Reported TM-21 Lifetimes
	RB1	85 °C	85 °C	250 mA	10	6,048 hrs	L90(6k) > 33,300 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs
Royal Blue	RB2	105 °C	105°C	250 mA	10	6,048 hrs	L90(6k) = 19,200 hrs L80(6k) > 33,300 hrs L70(6k) > 33,300 hrs



#### XLAMP® XQ-A WHITE LEDS (REV 0)

Revision: 0 (September 15, 2016)

**Description Of LED Light Sources** 

XLamp XQ-A White LEDs (Series: XQAAWT)

This LM-80 report is applicable to the following order codes:

XQAAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	250 mA	3000 K	20	6,048 hrs	L90(6k) = 30,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	105 °C	105 °C	250 mA	3000 K	20	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XQ-B WHITE LEDS (REV 1)

Revision: 1 (October 15, 2013)

**Description Of LED Light Sources** 

XLamp XQ-B White LEDs (Series: XQBAWT)

This LM-80 report is applicable to the following order codes:

XQBAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
3	85 °C	85 °C	100 mA	3000 K	25	6,048 hrs	L90(6k) = 17,200 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
1	85 °C	85 °C	200 mA	3000 K	25	6,048 hrs	L90(6k) = 11,600 hrs L80(6k) = 24,600 hrs L70(6k) > 36,300 hrs
2	105 °C	105 °C	200 mA	3000 K	25	6,048 hrs	L90(6k) = 8,440 hrs L80(6k) = 18,800 hrs L70(6k) = 30,500 hrs



#### XLAMP® XQ-D WHITE LEDS (REV 0)

Revision: 0 (October 14, 2013)

**Description Of LED Light Sources** 

XLamp XQ-D White LEDs (Series: XQDAWT)

This LM-80 report is applicable to the following order codes:

XQDAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	105 °C	105 °C	500 mA	3000 K	25	7,560 hrs	L90(8k) = 13,800 hrs L80(8k) = 32,500 hrs L70(8k) > 45,400 hrs
2	105 °C	105 °C	700 mA	3000 K	25	6,048 hrs	L90(6k) = 12,500 hrs L80(6k) = 30,100 hrs L70(6k) > 36,300 hrs



### XLAMP® XQ-E RED, RED-ORANGE, PHOSPHOR-CONVERTED AMBER, GREEN, BLUE & ROYAL BLUE LEDS (REV 0)

Revision: 0 (March 30, 2016)

### **Description Of LED Light Sources**

XLamp XQ-E Red LEDs (Series: XQERED)

XLamp XQ-E Red-Orange LEDs (Series: XQERDO)

XLamp XQ-E Phosphor-Converted Amber LEDs (Series: XQEAPA)

XLamp XQ-E Green LEDs (Series: XQEGRN)
XLamp XQ-E Blue LEDs (Series: XQEBLU)
XLamp XQ-E Royal Blue LEDs (Series: XQEROY

This LM-80 report is applicable to the following order codes:

XQERED-xx-xxxx-xxxxxxxx

XQERDO-xx-xxxx-xxxxxxxx

XQEAPA-xx-xxxx-xxxxxxxx

XQEGRN-xx-xxxx-xxxxxxxx

XQEBLU-xx-xxxx-xxxxxxxx

XQEROY-xx-xxxx-xxxxxxxx

No failures occurred during testing.

LED Color	Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	Sample Count	Test Duration	Reported TM-21 Lifetimes
Red,	R1	85 °C	85 °C	1000 mA	25	12,096 hrs	L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
Red-Orange	R2	105 °C	105 °C	1000 mA	25	12,096 hrs	L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
	PCA1	105 °C	105 °C	700 mA	20	9,576 hrs	L90(10k) = 10,500 hrs L80(10k) = 29,400 hrs L70(10k) = 50,800 hrs
Phosphor- Converted Amber	PCA2	85 °C	85 °C	1000 mA	20	9,072 hrs	L90(9k) = 10,600 hrs L80(9k) = 33,000 hrs L70(9k) > 54,400 hrs
	PCA3	105 °C	105 °C	1000 mA	20	6,048 hrs	L90(6k) = 9,490 hrs L80(6k) = 19,000 hrs L70(6k) = 29,800 hrs



# XLAMP® XQ-E RED, RED-ORANGE, PHOSPHOR-CONVERTED AMBER, GREEN, BLUE & ROYAL BLUE LEDS (REV 0) - CONTINUED

LED Color	Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	Sample Count	Test Duration	Reported TM-21 Lifetimes
	G1	85 °C	85 °C	500 mA	20	8,064 hrs	L90(8k) > 48,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
Green	G2	105 °C	105 °C	500 mA	20	8,064 hrs	L90(8k) > 48,400 hrs L80(8k) > 48,400 hrs L70(8k) > 48,400 hrs
Green	G3	85 °C	85 °C	1000 mA	20	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
	G4	105 °C	105 °C	1000 mA	20	6,048 hrs	L90(6k) = 22,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
	B1	85 °C	85 °C	500 mA	20	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
Blue	B2	105 °C	105 °C	500 mA	20	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
blue	В3	85 °C	85 °C	1000 mA	20	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
	B4	105 °C	105 °C	1000 mA	20	7,560 hrs	L90(8k) > 45,400 hrs L80(8k) > 45,400 hrs L70(8k) > 45,400 hrs
Royal Blue	RB1	85 °C	85 °C	1000 mA	17	11,592 hrs	L90(12k) > 63,800 hrs L80(12k) > 63,800 hrs L70(12k) > 63,800 hrs
noyal blue	RB2	105 °C	105 °C	1000 mA	19	11,592 hrs	L90(12k) > 63,800 hrs L80(12k) > 63,800 hrs L70(12k) > 63,800 hrs



#### XLAMP® XQ-E WHITE LEDS (REV 0)

Revision: 0 (December 11, 2014)

**Description Of LED Light Sources** 

XLamp XQ-E White LEDs (Series: XQEAWT)

This LM-80 report is applicable to the following order codes:

XQEAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	85 °C	85 °C	500 mA	3000 K	25	8,568 hrs	L90(9k) = 28,300 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
2	105 °C	105 °C	500 mA	3000 K	25	8,568 hrs	L90(9k) = 25,500 hrs L80(9k) > 51,400 hrs L70(9k) > 51,400 hrs
3	85 °C	85 °C	700 mA	3000 K	25	6,048 hrs	L90(6k) = 24,700 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4	105 °C	105 °C	700 mA	3000 K	25	6,048 hrs	L90(6k) = 19,900 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XR-E WHITE LEDS (REV 1)

Revision: 1 (September 20, 2010)

### **Description Of LED Light Sources**

XLamp XR-E White LEDs (Series: XREWHT)

This LM-80 report is applicable to the following order codes:

XREWHT-xx-xxxx-xxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	25 °C	25 °C	350 mA	6200 K	30	9,072 hrs	L90(9k) = 28,500 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
2	25 °C	25 °C	350 mA	2700 K	30	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
5	45 °C	45 °C	350 mA	6000 K	19	6,846 hrs	L90(7k) = 26,600 hrs L80(7k) > 37,700 hrs L70(7k) > 37,700 hrs
7	55 °C	55 °C	350 mA	6500 K	30	11,088 hrs	L90(11k) = 12,400 hrs L80(11k) = 22,400 hrs L70(11k) = 33,700 hrs
8	55 °C	55 °C	350 mA	2700 K	29	10,080 hrs	L90(10k) = 13,000 hrs L80(10k) = 23,500 hrs L70(10k) = 35,500 hrs
11	85 °C	85 °C	350 mA	6000 K	30	7,560 hrs	L90(8k) = 10,000 hrs L80(8k) = 19,300 hrs L70(8k) = 29,900 hrs
12	85 °C	85 °C	350 mA	3000 K	30	8,544 hrs	L90(9k) = 11,500 hrs L80(9k) = 20,500 hrs L70(9k) = 30,800 hrs
3	25 °C	25 °C	700 mA	6200 K	30	9,072 hrs	L90(9k) = 29,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
4	25 °C	25 °C	700 mA	2700 K	30	9,072 hrs	L90(9k) > 54,400 hrs L80(9k) > 54,400 hrs L70(9k) > 54,400 hrs
6	45 °C	45 °C	1000 mA	6500 K	20	14,616 hrs	L90(15k) = 19,100 hrs L80(15k) = 37,900 hrs L70(15k) = 59,200 hrs
9	55 °C	55 °C	1000 mA	6200 K	29	11,592 hrs	L90(12k) = 17,100 hrs L80(12k) = 37,500 hrs L70(12k) = 60,600 hrs
10	55 °C	55 °C	1000 mA	4500 K	30	10,080 hrs	L90(10k) = 12,600 hrs L80(10k) = 24,800 hrs L70(10k) = 38,700 hrs



#### XLAMP® XR-E WHITE LEDS (REV 1) - CONTINUED

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
13	85 °C	85 °C	1000 mA	6500 K	30	6,048 hrs	L90(6k) = 12,900 hrs L80(6k) = 26,500 hrs L70(6k) > 36,300 hrs



#### XLAMP® XT-E HIGH VOLTAGE WHITE LEDS (REV 0)

Revision: 0 (August 21, 2012)

### **Description Of LED Light Sources**

XLamp XT-E High Voltage White LEDs (Series: XTEHVW)

This LM-80 report is applicable to the following order codes:

XTEHVW-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
1	55 °C	55 °C	44 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
2	85 °C	85 °C	44 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
3	105 °C	105 °C	44 mA	3000 K	25	6,048 hrs	L90(6k) = 13,500 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
4	55 °C	55 °C	66 mA	3000 K	25	6,048 hrs	L90(6k) = 25,100 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs
5	85 °C	85 °C	66 mA	3000 K	25	6,048 hrs	L90(6k) > 36,300 hrs L80(6k) > 36,300 hrs L70(6k) > 36,300 hrs



#### XLAMP® XT-E WHITE LEDS (REV 10)

Revision: 10 (September 22, 2016)

### **Description Of LED Light Sources**

XLamp XT-E White LEDs (Series: XTEAWT)

This LM-80 report is applicable to the following order codes:

XTEAWT-xx-xxxx-xxxxxxxx

No failures occurred during testing.

Data Set	Case Temp. [T <sub>s</sub> ]	Ambient Temp. [T <sub>A</sub> ]	Drive Current [I <sub>F</sub> ]	ANSI CCT Target	Sample Count	Test Duration	Reported TM-21 Lifetimes
8	85 °C	85 °C	500 mA	3000 K	20	12,096 hrs	L90(12k) > 72,600 hrs L80(12k) > 72,600 hrs L70(12k) > 72,600 hrs
9	105 °C	105 °C	500 mA	3000 K	20	13,104 hrs	L90(13k) > 78,600 hrs L80(13k) > 78,600 hrs L70(13K) > 78,600 hrs
3+	55 °C	55 °C	1000 mA	3000 K	16	18,144 hrs	L90(18k) = 45,600 hrs L80(18k) = 88,500 hrs L70(18k) > 99,800 hrs
10	85 °C	85 °C	1000 mA	3000 K	20	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
11	105 °C	105 °C	1000 mA	3000 K	20	10,080 hrs	L90(10k) > 60,500 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
5	55 °C	55 °C	1250 mA	3000 K	25	10,080 hrs	L90(10k) = 46,100 hrs L80(10k) > 60,500 hrs L70(10k) > 60,500 hrs
6	85 °C	85 °C	1250 mA	3000 K	25	9,072 hrs	L90(9k) = 19,300 hrs L80(9k) = 41,400 hrs L70(9k) > 54,400 hrs